



SR052/060-FRAME GROUP




Ref No	Part No	Part Name	Q'ty		Price
			052	060	
1	S052-106000	Shaft, Driver	1		
	S060-106000	Shaft, Driver		1	
2	0250-507208	Seal, Oil	2	2	
3	0800-000072	Ring, Snap	1	1	
4	0121-006207	Bearing, Ball	1	1	
5	1450-200021	Outside flange	1	1	
6	0321-010030	Bolt	6	6	
7	0931-010000	Washer, Packing	6	6	
8	1450-200020	Packing, Outside flange	1	1	
9	S060-102000	Mission job	1	1	
10	S060-101010	Master L	1	1	
11	S060-101020	Master R	1	1	
12	0321-016040	Bolt	8	8	
13	0410-016000	Washer, Spring	8	8	
14	0421-016000	Nut	4	4	
15	0321-016100	Bolt	1	1	
16	S060-101030	Collar	1	1	
17	0931-016000	Washer, Spring	1	1	
18	0410-016001	Nut	1	1	
19	1731-103000	Pin, Top Link	1	1	
20	1109-319000	Pin, R-Shape	1	1	
21	S060-105000	Carrier	1	1	
22	S052-104000	Cover, Shaft Driver	1		
	S060-104000	Cover, Shaft Driver		1	
23	0310-008020	Bolt w/washer	4	4	
24	1450-200052	Pubber cap	1	1	

SR052/060-COVER GROUP




Ref No	Part No	Part Name	Q'ty		Price
			052	060	
1	S052-201000	Cover, Tillage	1		
	S060-201000	Cover, Tillage		1	
2	S052-202000	Cover, Front	1		
	S060-202000	Cover, Front		1	
3	S050-202010	Plate, Press	1		
	S060-202010	Plate, Press		1	
4	0310-010030	Bolt	6	6	
5	0931-010000	Washer, Spring	6	6	
6	0421-010000	Nut	6	6	
7	S060-103000	U Bolt	2	2	
8	0421-012000	Nut	2	2	
9	S060-601000	Arm, Link	2	2	
10	S060-103000	U Bolt	2	2	
11	0421-012000	Nut	2	2	
12	1750-600006	Pin, Lower Link	2	2	
13	1461-306000	Pin, Ring	2	2	
14	0310-010025	Bolt	6	6	
15	0931-010000	Washer, Spring	6	6	
16	0421-010000	Nut	6	6	
17	S060-203000	Bracket	2	2	
18	0310-010030	Bolt	4	4	
19	0931-010000	Washer, Spring	4	4	
20	0421-010000	Nut	4	4	
21	0310-012030	Bolt	2	2	
22	0931-012000	Washer, Spring	2	2	
23	0421-012000	Nut	2	2	
24	0310-010025	Bolt	3	3	
25	0931-010000	Washer, Spring	3	3	
26	0421-010000	Nut	3	3	
27	S052-301000	Plate, Balance	1		
	S060-301000	Plate, Balance		1	
28	C060-302000	Chain	1	1	
29	0851-012040	Pin	1	1	
30	0832-103222	Pin, Split	1	1	
31	0930-013000	Washer, Plain	1	1	
32	S060-204000	Stand	1	1	
33	0310-010055	Bolt	1	1	
34	0931-010000	Washer, Spring	1	1	
35	0410-010000	Nut	1	1	
36	0851-010055	Pin	1	1	
37	1109-020000	Pin-R Shape	1	1	

SR052/060-MISSION GROUP




Ref No	Part No	Part Name	Q'ty		Price
			052	060	
1	1450-200001	Case, Mission	1	1	
2	0120-030208	Bearing, Taper	2	2	
3	S060-107000	11T Gear Bevel	1	1	
4	1450-200003	Cover, Inout Shaft Packing	1	1	
5	1450-200004	Cover, Inout Shaft	1	1	
6	0310-008020	Bolt w/washer	4	4	
7	1650-300006	M39 Nut	1	1	
8	0250-358010	Seal, Oil	1	1	
9	1450-200005	Cover, Inout Shaft	1	1	
10	0310-008020	Bolt w/washer	4	4	
11	1450-200006	Feed Shaft	1	1	
12	S060-108000	26T Gear Bevel	1	1	
13	0120-006210	Bearing, Ball	2	2	
14	1450-200008	Shim	1	1	
15	0800-000090	Ring, Snap	2	2	
16	0250-509012	Seal, Oil	2	2	
17	1331-106000	Gauge, Oil	1	1	
18	0321-010014	Bolt	1	1	
19	0920-010000	Washer, Packing	1	1	

SR052/060-SIDER GEAR GROUP 1



NO	PART NO	PART NAME	Q'ty		Price
			052	060	
1	S060-401000	Plate, Chain Case	1	1	
2	1450-200014	Collar	1	1	
3	1450-200012	11T Sprocket	1	1	
4	1450-200013	M30 Nut	1	1	
5	1450-200019	Tension, Chain	1	1	
6	0930-013000	Washer, Plain	1	1	
7	0832-103222	Pin, Split	1	1	
8	0320-760053	Seal, Group	1	1	
9	0250-951213	Seal, Oil	1	1	
10	1450-200026	Boss, Tillage	1	1	
11	1450-200033	Packing, Boss, Tillage	1	1	
12	0321-010030	Bolt w/washer	6	6	
13	0310-062090	Bearing, Ball	1	1	
14	0330-085000	Ring, Snap	1	1	
15	1450-200015	Collar	1	1	
16	1450-200016	16T Sprocket	1	1	
17	1450-200017	M35 Nut	1	1	
18	S060-403000	Chain	1	1	
19	1450-200011	Packing, Plate	1	1	
20	1450-200009	Cover, Chain	1	1	
21	0320-010030	Bolt	4	4	
22	0931-010000	Washer, Spring	4	4	
23	0410-010001	Nut	4	4	
24	0320-008020	Bolt	20	20	
25	0410-008000	Nut	20	20	
26	1500-500030/1	Cap Filling	1	1	
27	0321-010014	Bolt	2	2	
28	0931-012000	Washer, Spring	2	2	

SR052/060-SIDER GEAR GROUP 2



NO	PART NO	PART NAME	Q'ty		Price
			052	060	
28	1450-200025	Shaft, Spline	1	1	
29	S052-501000	Shaft, Tillage	1		
	S060-501000	Shaft, Tillage		1	
30	0321-010022	Bolt w/washer	6	6	
31	0321-010025	Bolt w/washer	6	6	
32	0321-012035	Bolt	60	72	
33	0931-012000	Washer, Spring	60	72	
34	0410-012000	Nut	60	72	
35	1450-200029	Blade, LH	15	18	
36	1450-200030	Blade, RH	15	18	
37	1450-200031	Shaft, RH	1	1	
38	0310-062070	Bearing, Ball	1	1	
39	0320-760042	Seal, Group	1	1	
40	1450-200032	Boss, Tillage	1	1	
41	1450-200033-1	Packing	2	2	
42	S060-402000	Bracket	1	1	
43	1450-200013	M30 Nut	1	1	
44	1450-200034	Cover, Bearing	1	1	
45	0231-080001	plug, grease	1	1	
46	0321-010030	Bolt w/washer	4	4	
47	Y1607-120	Skid LH	1	1	
48	Y1607-130	Skid RH	1	1	
49	0310-012035	Bolt	4	4	
50	0931-012000	Washer, Spring	4	4	
51	0410-012000	Nut	4	4	